



N O . 3 0 1 S E R I E S

- 1) Screw wall plates onto arms using three 2" wood screws for each arm.
- 2) Lay the left hand arm on its' side. Select the shelf bar which contains the plugs and insert it into position #2. Insert the 3 remaining shelf bars and hanger bar. Be sure the hanger bar is positioned as illustrated above.
- 3) Being VERY CAREFUL not to scratch finish, insert right hand arm onto the shelf and hanger bars.
- 4) Secure the #2 shelf bar to each arm with the two $\frac{1}{4}$ " machine screws and finishing washers.
- 5) Insert the hanger bar set screws. Be sure the hanger bar is positioned so that the set screws will enter the bottom slot of the hanger bar.
- 6) After mounting assembled unit on wall, insert silver buttons into top and bottom holes on wall plates.
- 7) If hangers do not slide freely in hanger bar, check bottom slot for a restricted area. Insert screwdriver into restricted area and carefully rotate screwdriver just enough to widen restriction.